

AKUSENSE

Intelligent Code Reader RCD-AI100-X Series User Manual



V1.0

Catalogue

Chapter 1: Product Introduction	3
1.1 product description	3
1.2 Main features	3
1.3 Appearance	4
1.4 Interface & bulk line definition	6
1.5 Accessories and dimensions	7
Chapter 2 Equipment Installation and Operation	9
2.1 Equipment installation	9
2.2 Power supply connection	11
2.3 Communication connection	13
Chapter 3 IO Electrical Characteristics and Wiring	14
3.1 I / O electrical characteristics	14
3.2 IO external wiring	17
3.3 RS-232 serial port	19
Chapter 4 Client operation	20
4.1 Software Connection	20
4.2 PC network configuration	21
4.3 Firmware upgrade	23
Chapter 5 function Introduction	24
5.1 Introduction of the interface	24
5.2 Read code configuration	26
5.3 The algorithm configuration	34

5.4 Trigger the configuration	42
5.5 Format configuration	50
5.6 Output configuration	59
5.7 Communication configuration	61
5.8 Configuration management	70
5.9 Settings	72
Chapter 6 Frequently Asked Questions	75
6.1 Client software identified the device but showed "inaccessible"	75
6.2 After Setting the debugging mode, the client is not saved	77
6.3 The barcode material is metal / PCB, with clear focus but unrecognition	77
6.4 The smaller bar codes cannot be identified	78
6.5 How to use the various trigger modes of the client software	79
6.6 Network trigger was unsuccessful	80

Chapter 1: Product Introduction

1.1 product description

This manual is applicable to the Meiji intelligent code reader RCD-AI100-X series, which can be applied to 3C, pharmaceutical food, electronic semiconductor, auto parts and other industries. The device uses sensors and optical

1.2 Main features

- Built-in deep learning algorithm, which can quickly locate the bar code and decoding
- Mechanical zoom lens, support remote and wide field reading
- Provide red / white two-color light sources, 4 groups of independent control light sources, and support polarized light sources to cope with complex scenes
- Support for ultra-small code reading, to meet the reading requirements of different distances
- Provide a rich IO interface to access multiple input and output signals
- IP67 protection, fearless of harsh industrial application environment

1.3 Appearance


A .Appearance instructions



NO.	Name	Description
1	Imaging sensor	For collect images
2	Light source	Built-in red / white light source
3	Positioning lamp	Indicates image center position
4	Screw holes	Code reader mounting holes
5	TRIG key	Trigger the button
6	TUNE key	Automatic reference button
7	Status indicator	Indicator light panel
8	12 Pin interface	M12-12 Pin interface

9	8 Pin interface	M12-8 Pin interface
---	-----------------	---------------------


B Status indicator light description




NO.	Name	Description
1	TRIG key	Trigger the button
2	TUNE key	Trigger the button
3	Power light	The green light is on for normal operation
4	Configuration indicator	The trigger button successfully triggers the green light
5	OK/NG indicator	Read code success green light, read code failure red light
6	Network indicator	Normal green light, data transmission strobe light
7	Error indicator	By default, the device is not on

1.4 Interface & bulk line definition

The equipment interface is M12-12 PIN and M12-8 PIN connector, and the specific pin signal definition is shown in the following figure. When wiring the equipment, please connect according to the pin number in the table and the color on the cable label.





M12-12 PIN pin	Pin No.	Color	Signal
	1	yellow	OUT2
	2	Green belt yellow edge	RS232_TxD
	3	brown	RS232_RxD
	4	pink	RS232_GND
	5	purple	IN1
	6	white	IN_COM
	7	red	VIN_24V
	8	black	DGND
	9	green	OUT_COM
	10	orange	IN0
	11	blue	OUT0
	12	gray	OUT1

M12-8PIN pin	Pin No.	Color
	1	Orange white
	2	Orange
	3	Green white
	4	Green
	5	Blue and white
	6	Blue
	7	Brown white
	8	Brown


1.5 Accessories and dimensions

A list

For the normal use of the equipment, please prepare the supporting items shown in the following table before installation.

Name	Description	picture
M12-12 PIN Interface line	M12 male head, RS232 communication interface, power interface, IO port, 3 m	
M12-8 PIN Interface line	M12 head, RJ45 network cable, 3 m	
source	The 24V power supply adapter	
Install accessories	L-shaped mounting bracket + screws	


B Appearance




Chapter 2 Equipment Installation and Operation

2.1 Equipment installation


1. Install the equipment to the fixing bracket and then to other mechanism parts through the fixing bracket.



2. Connect the M12-12 PIN interface line, please access and lock the screw in the correct way.




3. Connect the M12-8 PIN interface line, please access and lock the screw in the correct way.




4. Installation height range: 100mm-1000mm, installation tilt 10-15 degrees, to avoid light spots and reflection.


The focal length was 8mm



The focal length was 12mm




The focal length was 16mm



2.2 Power supply connection


There are two power supply methods: support 24VDC direct connection or 220VAC with adapter connection, maximum 3A.

A for an external direct supply of 24V



B External direct supply of 220V


Power power with an adapter.



2.3 Communication connection


A RS232 Serial port

The default port rate is 9600, check bit: NULL, data bit: 8, stop bit: 1, can be changed according to the actual situation.



B Ethernet

The default IP address is 192.168.0.100 and the received data port is 15000 and can be changed according to the actual situation.



Chapter 3 IO Electrical Characteristics and Wiring

3.1 I / O electrical characteristics

The Line In 0 / 1 in the device I / O signal is the optical coupling isolation input, and the Line Out 0 / 1 / 2 is the optical coupling isolation output.

3.1.1 Input electrical characteristics

The parameter name	Parameter symbol	parameter values
Enter the logic to the low level	VOL	8V
Enter the logic high level	VOH	12V
Input drops along the delay	TDF	1.3 μ s
Input rise edge delay	TDR	35 μ s

*Description *: The input logic is low or logic high, which is the threshold of the voltage representing the input. Input up or down delay is the representative performance.*


3.1.2 Output electrical characteristics

The parameter name	Parameter symbol	parameter values
Output logic is at a low level	VOL	0.7V
Output logic is at a high level	VOH	23.9V
Output drops along the delay	TDF	7.5 μ s
Output rises along the delay	TDR	141 μ s
Output drop time	TF	12.6 μ s
Output up time	TR	157.8 μ s

3.1.3 Input the internal wiring diagram


- incoming signal

In 0 / 1 in the device I / O signal is a photo coupled isolated input with an input voltage ranging from 8 to 24 VDC.



Equipment input circuit diagram

- The input logic level is:




Enter a logical level diagram

3.1.4 Input the internal wiring diagram


- output signal

The Lineout0 / 1 / 2 in the device I / O signal is the optical coupling isolation output. The output voltage range is from 5 to 40 V.



Equipment output circuit diagram

- The output logic level is:



Output logic level diagram

3.2 IO external wiring

The device may receive the external input signal or the output signal to the external device through the I / O interface. This section mainly introduces how to connect the I / O part.


The signal input in the wiring diagram takes LineIn 0 as an example, and the signal output

takes LineOut 0 as an example. Other interfaces can be similar according to the cable definition in the wiring diagram and combined with the interface introduction.


3.2.1 Input the external wiring diagram

Different types of equipment, equipment input wiring is different.

- The input signal is the NPN




- The input signal is the PNP



3.2.2 Output the external wiring diagram

Different types of equipment have different output wiring of the equipment.

- External equipment is NPN, type equipment



*explain *:*


- 1) The voltage value of the VCC of the equipment shall not be higher than the voltage value of the reader PWR, otherwise the output signal of the equipment will be abnormal.
- 2) The output load current shall meet the product specifications (serial flow resistance if necessary).

3.3 RS-232 serial port

The device supports the RS-232 serial port output.

3.3.1 RS-232 serial port

The common oral definition of the 9-pin header 232 serial port connector string is shown in the figure below.



9-The pin male header connector

PIN NO.	IMPLICATIONS	FUNCTIONAL DESCRIPTION
2	RX	RECEIVE DATA
3	TX	SEND DATA
5	GND	SIGNAL GROUND

9-pin header 232 serial port definition

*Note *: The voltage value of VCC shall not be higher than that of PWR, otherwise the output signal of the equipment will be abnormal.*

Chapter 4 Client operation

4.1 Software Connection

- Double-click on the icon to open the software;

- The intelligent code reader and the PC of the configuration software need to be connected in the same network segment;
- Default IP address: 169.254.153.0; Gateway 255.255.0.0;
- You can use the DHCP and use the static IP address form to make the connection successful.

IP configuration

Setting mode

Use DHCP Use static IP

Static IP configuration

Configuration... 以太网 One-click matching

IP address 192 . 168 . 1 . 34

Subnet mask 255 . 255 . 255 . 0

[more](#)


Default gateway 0 . 0 . 0 . 0

DNE Server 114 . 114 . 114 . 114


4.2 PC network configuration

4.2.1 Change the IP address of the PC

The operation steps are as follows: 1) Take Windows10 as an example, open "Start menu"> "Settings"> "Network and Internet"> "Ethernet"> "More Adapter option"> "Ethernet 3"> Right click "Properties"> "Network"> "Internet Protocol v 4 (TCP / IPv4); the IP address of the corresponding PC card is 169.254.153.16; Subnet mask: 255.255.0.0.




2) Open the configuration software, select the corresponding product and click the connection to complete.



4.2.2 Change the IP address of the reader



The operation steps are as follows: open the configuration software, select the corresponding PC network card, display to the code reader, click IP Settings> Use static IP> One-key Match> confirmation, change the IP address to the same network segment IP

as the PC.



4.3 Firmware upgrade

The steps are as follows: Device Management> Device Operation> Firmware upgrade, select the firmware file, and then click OK for the firmware update. Wait for the restart to complete.




Chapter 5 function Introduction

5.1 Introduction of the interface

The device can operate through the client, specifically as follows:

- 1) Ensure that the device is accessible, and click the "Connect" of the client.
- 2) After connecting the device, the main interface of the client is shown in the following figure. See the table for the introduction of each functional module.



order number	name	Brief description of function
1	menu bar	Set up the client base functions.
2	Configuration of the reader	Menu bar secondary menu, set the parameters of the corresponding module, including template selection, parameter setting, algorithm setting, etc.
3	Tool bar	You can start / stop image acquisition for the device, but also can grasp the map saving, cancel ROI, zoom in and out of preview map, software trigger and other shortcut operations.
4	Preview window	It can preview the currently collected images of the device, the algorithm to read, and draw the effect of the ROI window.
5	history	Display the barcode information currently read by the client in real time.


6	Basic Settings	You can change the device name, buzzer setting, button setting, and you can also count the device reading information, firmware upgrade, view the device log information, etc.
---	----------------	--

5.2 Read code configuration

5.2.1 Template selection


Template type support "Template 1" to "Template 5", a total of 5 templates, as shown in the figure below.

Through the upper left corner pull-down of the "reader configuration" area of the device, the operation mode can be saved as "template".



5.2.2 Image acquisition


If the recognition effect is not good, you can adjust the parameters of "image acquisition" in "read code configuration", including manually adjusting the camera setting and light source setting, such as exposure time, gain, focus, light source parameters; or adaptive adjustment, and intelligently adjust the camera setting and light source setting through the device itself



5.2.2.1, adaptive parameter adjustment

Adaptive parameter adjustment content includes: image algorithm ROI, image adjustment, light source adaptation, automatic code system search. The user selects the


required adjustment parameters (image quality adaptive, light source, automatic focus, automatic code system search) and clicks to execute the automatic adjustment of exposure, gain, light source, code system and other parameters to achieve the best decoding effect, and the adjustment parameters will automatically set each parameter item.



5.2.2.2, Camera settings

- Exposure time: control the opening time of the reader shutter and control the brightness of the image. The longer the exposure time, the brighter the image collected. Can be adjusted by sliding or filling in the numbers;

- Gain index: control the image gain size, control the image brightness, can be adjusted by sliding or filling in the number;
- Tip: the greater the exposure time, the smaller the motion speed supporting reading; the greater the gain index, the more image noise;



5.2.2.3, Light source setting

Control all fill lights to control the opening and closing of four sets of fill lights, adjust the brightness of each group (1-24), 24 is the maximum brightness; select the corresponding lights, fill in the corresponding number in the light intensity setting, and click Save setting.

The screenshot shows the configuration interface for a scanner. The browser tab is titled "Device management" and "Scanner/192.168.1.88". The interface is divided into two main sections: "Image acquisition" and "Algorithm configuration". Under "Algorithm configuration", there are three expandable sections: "Adaptive parameters adjustment", "Camera setting", and "Light source setting". The "Light source setting" section is currently expanded, showing a central image of the scanner with four green light sources. Below the image, there are four numbered rows (1-4) for light source settings. Each row includes a numeric input field set to "24", a toggle switch, and a horizontal slider bar. At the bottom of the "Light source setting" section, there is a "Positioning lamp" toggle switch. The left sidebar contains several configuration options: "Code reading Configuration", "Trigger Configuration", "Format Configuration", "Output Configuration", "Communication Configuration", "Manage Configuration", and "Setting". At the bottom of the sidebar, there are buttons for "Default parameters" and "Save parameters".


5.3 The algorithm configuration

The device can set the relevant parameters of the reading algorithm through the "Algorithm configuration" module.

5.3.1 Read code type

At present, the code reading equipment supports two types of one-dimensional code and QR code. Check the code system of the bar code, which can be selected.

As shown in the figure below, then the algorithm configuration interface displays the selected code system. The more code system is selected, the time it takes for the algorithm to process each picture will increase. It is suggested to choose the corresponding code system according to the actual requirements to achieve the best effect.



5.3.2 Algorithm parameters

Set the decoding parameters of one-dimensional QR code.

- Polarity: used to represent the bar code and background color, the parameters

can be set to be white background black code and black background white code and compatible mode.

- Edge type: the parameter can be set as continuous code, discrete code and compatible mode.

Note: the continuous or discrete code to see whether the minimum cell of the code is connected together, connected together is the continuous code, separated for the discrete code.

- Mirror mode: used to distinguish whether the code is a mirror state, can set the parameters as mirror, non-mirror and compatible mode.
- QR distortion: used to determine whether the QR code has a distortion phenomenon, the parameters can be set as distortion, non-distortion and compatibility mode.
- DM code type: used to distinguish the DM code type, the parameters can be set as square, rectangle and compatible mode.
- Operation mode: select the mode for decoding, different modes have different time consumption and results, parameters can be set as top speed mode, ordinary mode and expert mode.
- Number of one-dimensional codes: the maximum number of output one-dimensional codes.
- Number of QR codes: the maximum number of QR codes used to output the QR codes.

Choose the template Template 2

⋮

Image acquisition

Algorithm configuration

QR

DM

Algorithm parameters ⌵

Algorithm time limit	<input type="text" value="2000"/>	ms
Image Preprocess	<input type="checkbox"/> Turn	
Algorithm type	<input type="text" value="Expert Mode"/>	
ISO code based rating standards	<input type="text" value="ISO1541x"/>	
ID/2D Barcode Configuration	<input type="text" value="One-dimensional code"/>	
Polarity	<input type="text" value="Compatibility Mode"/>	
Application Mode	<input type="text" value="Normal Mode"/>	
Code39 check	<input type="text" value="Off"/>	
ID Code Number	<input type="text" value="1"/>	
One-dimensional coding system rating	<input type="text" value="Off"/>	
Code based rating	<input type="text" value=""/>	

ROI setting under the decoding algorithm Turn on ⌵

Draw ROI manually	<input type="button" value="Draw"/>
Add multiple ROI in a batch	<input type="button" value="Draw"/>
Clear all ROI	<input type="button" value="Clear"/>

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

Choose the template Template 2

Image acquisition | Algorithm configuration

QR
 DM

Algorithm parameters

Algorithm time limit	<input type="text" value="2000"/> ms
Image Preprocess	<input type="checkbox"/> Turn
Algorithm type	<input type="text" value="Expert Mode"/>
ISO code based rating standards	<input type="text" value="ISO1541x"/>
1D/2D Barcode Configuration	<input type="text" value="QR code"/>
Polarity	<input type="text" value="Compatibility Mode"/>
Mirror Mode	<input type="text" value="Compatibility Mode"/>
Application Mode	<input type="text" value="Normal Mode"/>
QR Distortion	<input type="text" value="Turn on"/>
QRVersion	<input type="text" value="Close"/>
Edge Type	<input type="text" value="Compatibility Mode"/>
DM Type	<input type="text" value="Compatibility Mode"/>
DMVersion_1	<input type="text" value="Close"/>
2D Code Number	<input type="text" value="2"/>
QR mode	<input type="text" value="Model2"/>


Setting
Default parameters
Save parameters

5.3.3 The ROI setting of the decoding algorithm

The algorithm ROI can only identify the selected regions of interest of the device, and other areas do not do algorithm processing to improve the reading efficiency.

The device may set up a number of algorithm ROI areas and output the barcode results from small to large order according to the number of the algorithm ROI

regions where the barcode is located. The output rules are as follows: 1, bar code 2, bar code 3, bar code 4, barcode. If the barcode is not identified in the ROI area of an algorithm, the barcode information in the corresponding area is changed to the set noread character. Currently, it supports manual and batch addition of 2 algorithm ROI drawing methods, and supports all ROI.



5.3.4 Manual draw of the ROI

Click Set to enter the manual set ROI mode, you can drag to set the ROI size according to the requirements (the ROI size can be set through the center point X / Y, width and height fine), the box selection area is the area of interest of the algorithm.

- ① Center X: Center point X coordinate of the ROI box.
- ② Center Y: Center point Y coordinate of the ROI box.
- ③ Width: the number of pixels in the ROI horizontal direction.
- ④ Height: the number of pixels in the ROI vertical direction.

The screenshot displays the software interface for manual ROI drawing. On the left, a sidebar contains configuration options: Code reading configuration, Trigger Configuration, Format Configuration, Output Configuration, Communication Configuration, and Manage Configuration. The main panel is titled 'Choose the template' and shows 'Template 2' selected. It is divided into 'Image acquisition' and 'Algorithm configuration' sections. Under 'Type of code reading', several options are checked, including 'One-dimensional code', 'CODE128', 'CODE39', 'CODE93', 'Interleaved 2 of 5', 'EAN13', 'EAN8', 'PharmaCode', 'QR code', 'QR', and 'DM'. The 'Algorithm parameters' section has 'ROI setting under the decoding algorithm' turned on. A 'Draw ROI manually' button is highlighted with a red box. Below it, there are buttons for 'Add multiple ROI in a batch', 'Clear all ROI', 'Draw', and 'Clear'. The right side of the interface shows a live camera feed with a blue ROI box drawn over a grayscale image of a person's face. A 'Draw area' dialog box is open, showing the following values: Center point X: 618, Center point Y: 317, Width: 766, Height: 466. At the bottom, a status bar displays 'Success rate of reading: 0.66 (0.09%)', 'Resolution: 1280*700', 'Real-time frame rate: 0.0 frame/s', 'RGB: 115 115 115', 'Location: 846,484', and 'Number of barcodes: 0'. Below the status bar is a table with columns: Image ID, Image name, Type of barcode, Code reading result, Code length, Quality Grading, PPM, Task time (ms), and Decoding time (ms). The table contains several rows of data, all showing 'Adaptive parameter tuning...' as the code reading result.

Image ID	Image name	Type of barcode	Code reading result	Code length	Quality Grading	PPM	Task time (ms)	Decoding time (ms)
66	20230605161902885	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
65	20230605161902769	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
64	20230605161902607	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
63	20230605161902400	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
62	20230605161902263	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
61	20230605161902126	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
60	20230605161901986	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0

5.3.5 Batch-added ROI (checkerboard)

Used to batch-plot the ROI.

- ① Drawing area: center X: batch setting of area center point X coordinate, center Y:

batch setting of area center point Y coordinate, height: the number of pixels in the vertical

direction of the batch set area, width: the number of pixels in the horizontal direction of the batch set area (default is the maximum number of pixels).

② Spacing setting: ROI spacing between rows and rows; column spacing: spacing between ROU columns.

③ ROI number (row * column): Batch sets the number of rows and columns of the ROI (the maximum value is dynamically adjusted according to the drawing local size and row / column spacing size).

④ Generation: Determine the above settings.

The screenshot shows the software interface with a 'Draw area' dialog box open. The dialog box contains the following fields and values:

- Center point X: 628, Center point Y: 361
- Width: 779, Height: 408
- Spacing setting: Row spacing: 0, Column spacing: 0
- Row and column setting: Number of rows: 4, Number of columns: 3

Below the dialog box, a table displays the success rate of reading (0.009%), resolution (1280*800), real-time frame rate (0.0 frame/s), and a list of barcode images with their IDs, names, types, and results.

Image ID	Image name	Type of barcode	Code reading result	Code length	Quality Grading	PPM	Task time (ms)	Decoding time (ms)
132	20230605161446848	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
131	20230605161446732	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
130	20230605161446595	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
129	20230605161446437	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
128	20230605161446301	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
127	20230605161446164	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0
126	20230605161446028	AutoParam	Adaptive parameter tuning...	0	F	0.0	0	0

5.3.6 Clear all of the ROI

Used to clear all of the current ROIs.

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

Choose the template Template 2

Image acquisition | Algorithm configuration

Type of code reading

- One-dimensional code
 - CODE128
 - CODE39
 - CODE93
 - Interleaved 2 of 5
 - EAN13
 - EAN8
 - PharmaCode
- QR code
 - QR
 - DM

Algorithm parameters

ROI setting under the decoding algorithm Turn on


Draw ROI manually Draw

Add multiple ROI in a batch Draw

Clear all ROI Clear

5.4 Trigger the configuration

The trigger types include Continuous Trigger, IO Trigger, Software Trigger, Network Trigger, and Serial Port Trigger.



The trigger type is as follows

5.4.1 Continuous trigger

The continuous trigger indicates that the reader continuously triggers the pictures.

5.4.2 IO Trigger


The IO trigger indicates that the reader takes the trigger photo after receiving the signal. This trigger mode requires set after selecting Single (External) mode.


Task timeout: Set the maximum task time for a single trigger. When the trigger is turned on, and the timeout time is not closed, the forced closure is performed.


Default 9999, setting range of 10-9999.


5.4.2.1 Start to trigger


Open and close the start-triggered selection page.



 Code reading
Configuration



 Trigger
Configuration


 Format
Configuration


 Output
Configuration


 Communication
Configuration


 Manage
Configuration

 **Setting**

[Default parameters](#)
[Save parameters](#)

Trigger type IO trigger

IO trigger

Task timeout Timeout enable 9999 ms

The task time is fixed to a timeout time

Multiple Barcode termination Enable 1 Codes

Image collection mode Cache Mode

Maximum number of images 100

get image frequency 1 out of 1

IO anti shake time 2000 us

Trigger starts

Delay trigger 0 ms

Trigger signal Line0

Trigger form Rising edge

Trigger ends

Delay trigger 0 ms
Time range: 0-9,999ms

Trigger signal Line0

Trigger form Falling edge

5.4.2.2. End of the trigger

Open and close the termination trigger selection page.

- Delay trigger: the time set by the trigger delay on the start trigger page indicates the trigger signal. The reading is stopped at the time set when the

trigger delay on the termination trigger page indicates the termination trigger signal. The default is to 0ms. Set the range of 0ms-9999ms.

- Trigger signal: the trigger signals under the start trigger page are divided into "Line0" and "Line1", corresponding to the hardware trigger inputs IN 0 and IN 1 respectively; the trigger signals under the termination trigger page are divided into "Lin0" and "Line1", and the trigger inputs of the hardware are IN 0 and IN 1 respectively.

- Code reading Configuration
- Trigger Configuration
- Format Configuration
- Output Configuration
- Communication Configuration
- Manage Configuration
- Setting
- Default parameters
- Save parameters

Trigger type IO trigger

IO trigger

Task timeout Timeout enable ms

The task time is fixed to a timeout time

Multiple Barcode termination Enable Codes

Image collection mode Cache Mode

Maximum number of images

get image frequency 1 out of 1

IO anti shake time us

Trigger starts

Delay trigger ms

Trigger signal Line0

Trigger form Rising edge

Trigger ends

Delay trigger ms

Trigger signal Line0
Line0
Line1

Trigger form

- Trigger form: The trigger form under the start trigger page is divided into

"rising edge" and "falling edge". The up edge indicates when the reader receives the up signal and starts reading; the down edge starts reading when the reader receives the down signal. The trigger form under the termination trigger page is divided into "rising edge" and "falling edge". The up edge means that the reader receives the up edge signal and the reader receives the down edge signal.

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

[Default parameters](#)

[Save parameters](#)

Trigger type IO trigger

IO trigger

Task timeout Timeout enable 9999 ms

The task time is fixed to a timeout time

Multiple Barcode termination Enable 1 Codes

Image collection mode Cache Mode

Maximum number of images 100

get image frequency 1 out of 1

IO anti shake time 2000 us

Trigger starts

Delay trigger 0 ms

Trigger signal Line0

Trigger form Rising edge

Trigger ends

Delay trigger 0 ms

Trigger signal Line0

Trigger form

- Falling edge
- Rising edge
- Falling edge

5.4.3 Software trigger

By clicking the "software trigger" content, the reader can trigger photos.

5.4.4 Network Trigger

Set the maximum task time for a single trigger.

When the trigger is turned on, and the timeout time is not closed, the forced closure is performed. Set range 10-9999; maximum number of pictures range from 1-100.

5.5 Format configuration

The format configuration contains two plates: "Data Filter" and "Data Processing", which can set the filter rules and output data of the device.

Configuration of format

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

Data filtering ⌵

Data processing ⌵

Host networking data processing ⌴

Duplicate barcode filtering Close

Add device number Close

Networking separator

5.5.1 Data Filtering

Data filtering can be read by the device according to the set rules.

- Duplicate time filtering: when this function is enabled, the repeat code is not output during the set time; (30-30000)


Ex: When set to within 500ms, the code content is 123452. If it runs for many times within 500ms, the result value is output once;

- Read quantity filtering: when this function is enabled, if the same reading number exceeds the set value, it is not output; (1-100)


Ex: when set to 3, when the code content is 123452, the output number of 123452 can not exceed 3 times;


- Barcode length limit: when this function is enabled, only the code within the limit range is output;
- Specify the beginning: When the function is enabled, only the specified beginning code (can have multiple beginning);
- Specify the end: When this function is enabled, only the code with the specified end (can have multiple endings);
- Must include: when this function is enabled, the output meets the code that contains the set content (there can be multiple contents);
- Can not include: When this function is enabled, the output meets the code that does not contain the set content (can have multiple not included);
- Character digit offset: output from setting the bit (ex, code: 1232334, set to 3, code output information 2334);
- Output character requirements: full numbers: output numbers, letters: output letters, numbers or letters;


- Bar code verification: input the target character information to verify whether the above filtering conditions are met. Do not display without input, OK / NG, OK when the filtering conditions are met, and NG if it is not satisfied.



 Code reading
Configuration



 Trigger
Configuration


Format
Configuration


 Output
Configuration


 Communication
Configuration


 Manage
Configuration

 Setting

[Default parameters](#)
[Save parameters](#)

Configuration of format

Data filtering ^

Filtering of repeated time Close v

Filtering of repeated barcodes Close v

Duplicate barcode filtering Close

Filter Ignore NG Close

Barcode Filtered by Number Close v

Character numeric offset Close v

Barcode length limit Close v

Specify the beginning Close v

Specify the end Close v

Must contain Close v

Cannot contain Close v

Character requirement Close v

Barcode verification

Data processing v

Host networking data processing ^

Duplicate barcode filtering Close

Add device number Close

Networking separator

53

5.5.2 Data processing


The data processing section can set the barcode results output by the device. With different communication protocols selected, the specific parameters are different.

- Sort method: sort the code system output results, support multiple sorting rules:


- ① Bar code length ascending order: according to the barcode content length from small to large sorting.
- ② Bar code length in descending order: according to the content length of the bar code from large to small sorting.
- ③ Bar code type ascending sequence: one-dimensional code: code39,93,128, ITF 25, EAN; QR code: QR / DM.
- ④ Bar code type in descending order: QR code: DM / QR, 1 D code: EAN, ITF 2 / 5, code128,93,39.


Note: The subsequent new code system is arranged in sequential order according to the above combination.


- ⑤ ROI ascending sequence: according to the set ROI number from small to large sorting.
- ⑥ ROI descending order: according to the set ROI number.
- ⑦ Bar code center X liter / descending order: according to the code center X position from small to large sorting (descending order and vice versa).
- ⑧ Bar code center Y ascending / descending order: according to the code center Y position from small to large sorting (descending order and vice versa).
- ⑨ Bar code position ascending / descending order: according to X from small to large, Y from small to large order (descending order and vice versa).





- Bar code divider, semicolon (;), comma (,), slash (/), backslash (\), underline (_), middash (-).



 Code reading
Configuration



 Trigger
Configuration


 Format
Configuration


 Output
Configuration


 Communication
Configuration


 Manage
Configuration

 **Setting**

[Default parameters](#)
[Save parameters](#)

Configuration of format

Data filtering ▼

Data processing ▲

Sorting order Barcode length ascending order ▼

Barcode separator Semicolon (;) ▼

Data template

Output starts

Output ends

Barcode content

Vertex coordinates

Semicolon (;)

Semicolon (;)

Comma (,)

Slash (/)

Backslash (\)

Underscore (_)

Underline (-)

None

\r

\r\n

{code_content}

Qualified

No code displayed in ROI Close

Decoding failed to output characters

Output Length Close ▼ 24

Host networking data processing ▲

Duplicate barcode filtering Close







Add device number Close

- Data template

Used to process and edit the data.

- Output starts

It includes bar code content, bar code type, bar code Angle, vertex coordinates, quality level, ROI serial number, PPM, time, and return change.

- 
 Code reading Configuration
- 
 Trigger Configuration
- 
 Format Configuration
- 
 Output Configuration
- 
 Communication Configuration
- 
 Manage Configuration

⚙️ Setting

Default parameters

Save parameters

Configuration of format

Data filtering ▼

Data processing ▲

Sorting order Barcode length ascending order ▼

Barcode separator Semicolon (;) ▼

Data template

Output starts

Output ends

Barcode content	Type of barcode	Barcode angle
Vertex coordinates	Text input	ROI No.
PPM	Time	Barcode Quality
New line	Enter	Wrap
Hexadecimal input	Barcode quantity	Code length

Collapse ▲

```
{code_content}
```

Qualified

No code displayed in ROI Close

Decoding failed to output characters

- Output end

Contains text input, output begins, and output ends.

① Text input: an input for custom characters.

- ② Output Start / End: custom settings for start and end.
- ③ Preview content: Preview of editing content.
- ROI without read completion

No recognition code in the ROI area, and the output read code failed to associate characters.

- Output failed character

Used to define read failure characters.

5.6 Output configuration

The continuous output time is 0~9999ms, divided into 3 output.


5.6.1 OUT settings

The OUT setting can control three sets of different output control, divided into "OUTLINE1", "OUTLINE2" and "OUTLINE3" corresponding to the hardware trigger output "OUT 0", "OUT 1" and "OUT 2" respectively.

① OUTLINE1: You can select "OK", "Read code failure", "abnormal" three states. "OK" indicates the read success output signal; "read failure" means the read failure output signal; "abnormal" indicates the device self-test abnormal condition output signal.

② OUTLINE2: You can select "OK", "Read code failure", "abnormal" three states. "OK" indicates the read success output signal; "read failure" means the read failure output signal; "abnormal" indicates the device self-test abnormal condition output signal.

- ③OUTLINE3: You can select "OK", "Read code failure", "abnormal" three states."OK" indicates the read success output signal; "read failure" means the read failure output signal; "abnormal" indicates the device self-test abnormal condition output signal.
- ④ Output duration: the duration of the output signal, the default is 9ms, range 0-9999ms.



5.7 Communication configuration

The "Communication Configuration" section includes TCP and serial port to set the

communication protocol required for selecting the data transmission, which is related to the operation mode of the device.

5.7.1 Using the TCP Server protocol

Generally is the common TCP protocol communication, code scanner as Server end.

Configuration of communication TCP

Use the TCPServer protocol

IP address 192.168.1.88

Subnet mask 255.255.255.0

TCP port 15000

heartbeat

Heartbeat identifier: online

Use the ModbusTCP protocol

Server Client

Byte exchan State machine mode

Modbus service port 502

Device station No. 1

Transmission address 10

Length of transmission data bit 10

Trigger address 0

Length of trigger data bit 10

Use the MC protocol

Use TCPClient

Use EtherNet/IP protocol

Use Profinet

use fins

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

5.7.2 Using the ModbusTcp protocol

In addition to the TCPServer, you can also choose the ModbusTcp protocol, which needs to configure the Modbus service IP and the Modbus service port respectively.

- Service IP: Connect to the IP address of the corresponding device.
- Service port: to connect to the port number of the corresponding device.
- Equipment station number: the station number connecting the corresponding equipment.
- Transfer address: the address where the PLC transfer data.
- Transfer data bit length: the length of the data bytes.
- Trigger address: the PLC address required to trigger the camera.
- Trigger data bit length: the length of the required data bit to trigger.

Configuration of communication TCP

Use the TCPServer protocol

Use the ModbusTCP protocol

Server Client

Byte exchan State machine mode

Modbus service port 502

Device station No. 1

Transmission address 10

Length of transmission data bit 10

Trigger address 0

Length of trigger data bit 10

Use the MC protocol

Use TCPClient

Use EtherNet/IP protocol

Use Profinet

use fins

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

5.7.3 Using the MC protocol

The MC protocol requires a separate configuration of the MC service IP, the MC

service port, etc.

- Service IP: Connect to the IP address of the corresponding device.
- Service port: to connect to the port number of the corresponding device.
- Equipment station number: the station number connecting the corresponding equipment.
- Device network number: the network number connected to the corresponding device.
- Transfer address: the address where the PLC transfer data.
- Transfer data bit length: the length of the data bytes.

Configuration of communication TCP

Use the TCPServer protocol

Use the ModbusTCP protocol

Use the MC protocol

MC service IP	
MC service port	502
Device station No.	0
Device network No.	0
Transmission address	10
Length of transmission data bit	10
Trigger address	0
Length of trigger data bit	10

Use TCPClient

Use EtherNet/IP protocol

Use Profinet

use fins

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting


Default parameters


Save parameters


5.7.4 Serial port


When the communication protocol selects Serial, you can set the following parameters:


- Serial port rate: Set the serial port port rate at the receiving end.
- Serial port parity check: set the serial port check bit of the receiving end.
- Serial data bit: Set the serial data bit of the receiving end.
- Serial end bit: Set the serial stop bit of the receiver.


 Code reading Configuration


 Trigger Configuration

 Format Configuration

 Output Configuration

 Communication Configuration

 Manage Configuration

 Setting

Default parameters

Save parameters

Configuration of communication

Serial port Serial port

Serial port

Baud rate 9600

Parity check None

Data bit 8

Stop bit 1

Use the ModBusRTU protocol

Server Client

Byte exchange

Device station No. 2

Transmission address 10

Length of transmission data bit 10

Trigger address 0

Length of trigger data bit 10

5.7.5 Using the ModBusRTU protocol

- Equipment station number: the station number connecting the corresponding equipment.
- Transfer address: the address where the PLC transfer data.
- Transfer data bit length: the length of the data bytes.
- Trigger address: the PLC address required to trigger the camera.
- Trigger data bit length: the length of the required data bit to trigger.

5.8 Configuration management

Configuration management includes Restore All Default Configuration and Save All Configuration.

Code reading Configuration

Trigger Configuration

Format Configuration

Output Configuration

Communication Configuration

Manage Configuration

Setting

Default parameters

Save parameters

Manage configuration

Save Configuration

Configuration 1

Load Configuration

Configuration 1

Default Settings

Configuration 1

5.9 Settings

5.9.1 Equipment Settings

- device name


You can modify the reader device name. Support for Chinese, English, letters, characters, numbers, etc.

- The buzzer setting

The decoding can be opened after success / failure, and the sound can be set for 40ms, 80ms, and 120ms.


- Key Settings

Trigger the key, turn on / off. Function button, on / off. Position the light, turn it on / off.



5.9.3 Backup and Restore

The reader can back up information such as Settings to the PC, or restore Settings and restore factory Settings.



5.9.4 Log viewing


You can view the log level "ERROR", "WARN", "INFO", "DEBUG" and other content;

You can Refresh Log, Clear Log, and Export Log.

5.9.5 Storage configuration

- The reader will save the configuration. The Data Record, Decoded Image, Undecoded Map, and Original Map can be turned on / off.
- The PC will save the configuration. You can freely choose the saved path.
- Capture diagram configuration. You can save the scratch path.
- Grasping time: 1s~60min.

- Grab quantity: 2 ~ 10,000 pieces.



Chapter 6 Frequently Asked Questions

6.1 Client software identified the device but showed "inaccessible"

- probable cause:


- 1) The IP of the device and the network card connected to the device are not in the

same network segment.


2) The network card has acquired the IP of two different segments.

- **resolvent:**

1) By modifying the device IP mode, make the computer and the device in the same network segment.



3) Click the computer "Start" -search box enter "cmd" -right click administrator permission to run-input: netsh winsock reset, reset the network card information, restart the computer.




```
管理员: 命令提示符
C: \Users\junwe>ipconfig netsh winsock reset
Windows IP 配置
以太网适配器 以太网:

    连接特定的 DNS 后缀 . . . . . :
    IPv4地址 . . . . . : 192.168.1.90
    子网掩码 . . . . . : 255.255.255.0
    IPv4地址 . . . . . : 169.254.52.250
    子网掩码 . . . . . : 255.255.0.0
    默认网关 . . . . . : 192.168.1.1
```

6.2 After Setting the debugging mode, the client is not saved

- Possible reason: The system has temporarily stored the setting parameters and needs to save all the settings manually after the setting is complete.
- Solution: Click Configuration Management-Save All Configuration.
- **The specific operations are performed as follows:**




6.3 The barcode material is metal / PCB, with clear focus but unrecognition

- **probable cause:**

1) The identified material is black bottom, and the brightness of the reading area is too low.

2) The identified material is seriously reflective.



- **resolvent:**

1) Increase the Light Source value, or the Gain value to increase the brightness of the reading area.

2) Adjust the reader angle / material angle to avoid the direct light source and adjust the exposure and gain.

6.4 The smaller bar codes cannot be identified

- Possible reasons: the bar code in the field of vision is less, the accuracy of the bar code is not enough, resulting in the inability to identify.(One-dimensional code stable reading needs PPM 2, QR code stable reading PPM 3.)

* PPM: it is the minimum number of pixels occupied by the bar code module.

- **resolvent:**

- 1) Zoom: reduce the distance.

6.5 How to use the various trigger modes of the client software

- **resolvent:**

- 1) Network trigger: use third-party software to verify, the software set the reader for the network trigger, set the same port, the same trigger command, the same network IP segment (some routes may open IP isolation, need to be closed).
- 2) IO trigger: IO trigger signal line needs to be connected, the software sets the reader as IO trigger, the wiring should be the same as LINE 0 / 1, and the trigger command is the same [there will be two connections of NPN and PNP. General connection: IN 0 / IN 1 contact generator OUT line, IN _ COM line positive (nnp) or negative (ppp)].
- 3) Serial port trigger: need to connect DB9 terminal, software set correct COM port, same port rate, data bit, stop bit, check bit. Same as for the trigger command.
- 4) Software trigger: requires the client software and the code reader to connect to the same network segment.

6.6 Network trigger was unsuccessful

- Possible reason: Only client mode is currently supported on the device side.
- Solution: Adjust the PLC device network trigger mode.