





User's manual

- Thank you for choosing AKUSENSE. Please read the manual carefully before using this product.
- The product should be applied by someone with a certain level of electrical knowledge.
 - Please read and make sure that you understand how to operate the product before using it.
 - Please keep this manual readily accessible for future reference when needed.

Product Image




Appearance Dimensions




Wiring

Please use the matching cable and take care to avoid pulling the cable with excessive force.



Cable Plug	Wiring Definition(Standard)	Wiring Definitions (Economy)	Wiring Definitions (Wiring)
① Brown	DC+ Positive power	DC+	DC+
② Black	Switching output 1 or parameter copy	OUT1	OUT1
③ White	OUT2 Switching output		485A
④ Blue	AIO Analog output		485B
⑤ Orange	DC- Negative power supply	DC-	DC-

Output wiring instructions




Note: Out1 is multiplexed for switching and parameter copying function, !!! please switch it by setting.

Output modes


OUT1 and OUT2 [Note] *1 Three modes are selectable: "Simple mode", "Hysteresis mode", and "Window mode". For details on the settings, refer to Section 1.

Simple Mode



Air pressure setting value P, output is ON when the air pressure is greater than P, otherwise it is OFF.

Lag Mode



Air pressure setting value H/L, the output is ON continuously, when the air pressure is greater than H, the output is OFF until the air pressure is less than L.

Window mode




Air pressure setting value H/L, output is ON only when the air pressure value is between L and H, otherwise it is OFF.

- Note:
- In simple mode, the sub-screen corresponds to $\frac{H-L}{P-2}$; in other modes, the sub-screen is displayed accordingly.
 - HYS is the hysteresis value, and its size can be changed in the Expert Setup Mode.


Air Pressure Access

Universal connectors can be used to access the air pressure, the interface type can be male R1/8, G1/8 and NPT1/8, or female M5 size, depending on the actual needs of the choice. The torque should be controlled to be less than 9.8 NM for male threaded ports and less than 1NM for female threaded ports during fastening. In addition, to prevent air leakage, a suitable amount of packing tape can be wrapped around the threaded joint before tightening the pneumatic connector.




Note: Do not apply direct force to the plastic part during installation!

Basic operation under <Operation mode>





Note: *1. Short press, otherwise it will enter other setting mode.
*2. The upper limit value must be greater than the lower limit value.
*3. If OUT2 is set to OFF, the three interfaces in the dotted line box will not appear. In addition, there is no OUT2 setting item in the Economy and Communication section.

Enter the Setup menu



[Note] Press and hold **S** for 2 seconds to return to <Running Mode> in any interface of <Normal Setting Mode>; Press and hold **S** for 4 seconds to return to <Running Mode> in any interface of <Expert Setting Mode>.


Normal Setting Mode



Notes:

- *1. OUT1 is output by default and cannot be turned off; *2. Economy models, communication models do not have this setting; *3. Economy model, communication teach this setting as shown in the figure. *4. High pressure type can not be set to mHg, mmHg; low pressure type can not be set to MPa;
- *5. Press **S** for 2 seconds in any interface of <General Setting Mode> to exit the mode and return to the normal setting mode. *6. Communication models are unique, other series products directly skip the "MODBUS Address Setting" and "MODBUS Baud Rate Setting" two menus.

Enter the Setup menu




Note: *3. Color linkage mode means that when the OUT1/OUT2 output is valid, the screen display color will change (e.g. from green to red or from red to green). *4. Under the expert setting mode, long-pressing **S** for 4 seconds in any interface can exit the expert setting mode and return to the operation mode. *5. The communication model has unique settings, and other products directly skip this.

Installation


Mounting Method 1-Bracket Mounting

The mounting brackets (L-type and Z-type) are available for mounting in all four directions. Tightening torque $\lt; 0.5N \cdot m$, screw size M3*6.



Mounting Method 2 - Panel Mount

The matching panel mounting bracket kit is available for assembly. The kit contains 3 types of accessories, including fixings, snap fasteners and panel protectors, which can be flexibly matched according to actual needs.



Note: All of the above are optional accessories, and need to be selected separately when ordering.


SUPERSPEED Mode on and off

Turning on the mode can make the response speed faster, the fastest is 1ms!



Note: this function only supports the standard model products, the fastest response speed of economy and communication models is 2ms.

Press **S** and **A** at the same time in run mode until the display reads.



At this time, release the keys to complete the on and off operation.


Note: in order to ensure the response speed, the screen display update speed and key response speed will be appropriately reduced (in order to ensure that does not affect the normal use of the premise).

Explanation of the parameter copy function

- 1. The parameter copy function can copy the parameter setting values from (master) barometer to (slave) barometer.
- 2. Before using the parameter copy function, please make sure the barometer models are the same.*1
- 3. This function only supports one-to-one parameter copying.

Steps for use:

1. Consult this manual - J Expert Setting Mode, set the master barometer as the master and the slave barometer as the slave.
2. In the unpowered state, connect the wires according to the following diagram.



Note:

1. The Economy and Communication models do not have a single "parameter copy function".
2. The copy function is multiplexed with OUT1. When the copy function is enabled, the OUT1 output is invalid.

3. Turn on the power^① of the (master) and (slave) barometers at the same time, and the display will be as shown in Fig. on the right.



4. Please wait about 2 seconds until **COPY** is displayed, or **FRI L** will be displayed if it fails. If copying fails, please double check the settings and connections and try again.
4. After successful copying, the (slave) barometer will automatically revert to $\lt; \text{Operation Mode}$ and turn off the "Parameter Copy Function".
5. Repeat steps 1-3 to copy the (master) barometer parameter settings to another (slave) barometer. Note:
 - *2. If the two barometers are not synchronized, copying may fail.

Parameters Specifications

Model	MQ-10D	MQ-01D	MQ-20D	MQ-02D	MQ-30D	MQ-03D	
	Economy model (high pressure type)	Economy model (low pressure type)	Standard model (high pressure type)	Standard model (low pressure type)	Communication model (high pressure type)	Communication model (low pressure type)	
Rated Voltage Range	-0.101~-1.000MPa	-101.3~-101.3kPa	-0.101~-1.000MPa	-101.3~-101.3kPa	-0.101~-1.000MPa	-101.3~-101.3kPa	
Set Pressure Range	-0.100~-1.000MPa	-101.0~-101.0kPa	-0.100~-1.000MPa	-101.0~-101.0kPa	-0.100~-1.000MPa	-101.0~-101.0kPa	
Maximum Withstand Pressure	1.5MPa	500kPa	1.5MPa	500kPa	1.5MPa	500kPa	
Applicable Gases	Non-corrosive gases, non-flammable gases, ISO compliant ISO 8573-1:2010[7:4:4]						
Supply Voltage	12~24V DC \pm 10%						
Current Consumption	Up to 45mA (no load)						
Display Resolution in Different Pressure Units	kPa	—	0.1	—	0.1	—	0.1
	MPa	0.001	—	0.001	—	0.001	—
	kgf/cm ²	0.01	0.001	0.01	0.001	0.01	0.001
	bar	0.01	0.001	0.01	0.001	0.01	0.001
	psi	0.1	0.01	0.1	0.01	0.1	0.01
	mmHg	—	0.1	—	0.1	—	0.1
	inchHg	—	1	—	1	—	1
Comparison Output [Note] *1	NPN open collector output, Maximum load current: 100mA, Maximum supply voltage: 30VDC, Internal voltage drop: 1.5V			PNP open collector output, Maximum load current: 100mA, Maximum supply voltage: 24VDC, Internal voltage drop: 1.5V			
Voltage-type Analog Output [Note] *1	Output voltage: 15V \pm 2.5%F.S, linearity: \pm 1%F.S, output impedance: 1K Ω		Output voltage: 15V \pm 2.5%F.S, linearity: \pm 1%F.S, output impedance: 1K Ω		None		
Current-type Analog Output	None		Output Current: 4~20mA \pm 2.5%F.S, Linearity: \pm 1%F.S, Load Resistance: Min: 50 Ω , Max: 300 Ω @12V,6000@24V		None		
MODBUS *2	None		None		Yes		
Display Accuracy	\pm 1digits (Operating Temperature: 25 \pm 10°C)		\pm 1%F.S.		\pm 1%F.S.		
Repeat Accuracy	\pm 0.2%F.S \pm 2digits		\pm 0.2%F.S		\pm 2digits		
Response Time	2.0ms, 50ms, 100ms 250ms, 500ms, 2000ms *4		1ms *3, 2.0ms, 50ms, 100ms, 250ms, 500ms, 2000ms		2.0ms, 50ms, 100ms 250ms, 500ms, 2000ms		
Display	3-color (red, orange, yellow-green) display, Sampling rate (4 times/sec)						
Temperature Characteristics	1% F.S. or less, Comparison reference temperature 25°C or less, 0~50°C applicable range						
Operating Environment	0~50°C (No condensation, no ice) ; 35~85%RH (no water dew)						
Storage Environment	-10~50°C (No condensation, no ice) ; 35~85%RH (no water dew)						
Protection Level	IP40 / IP65*						
Receiver Caliber	Male thread: R1/8(Asian standard PT1/8), G1/8(European standard), NPT1/8(North American standard), Female thread: M5						
Weight	85g(Power cable included)						
Accessories	1 power cable with terminals, 1 instruction manual						

Note:

- *1 Output type corresponds to the product model - Only the flood model supports MODBUS mode, please refer to the Product Instruction Manual for its operation.
- *2 Turn on the SUPERSPEED mode to support 1ms response speed, about the opening and closing of this, please refer to the "Product Instruction Manual": "4".
- *3 For the setting of response speed, please refer to the instruction manual of the product.
- *4 For the setting of response speed, please refer to the instruction manual of the product.

MODBUS communication instructions

This product communication is fully compliant with MODBUS protocol standard, if necessary, please contact our company for detailed instructions (including code examples).

Data format	Address	Funtion	Data	CRC
single frame format	8bit	8bit	n*8bit	16bit
	1 start bit, 8 data bits, 2 stop bits, no parity bit			

Address	Register pointing	Corresponding value		corresponding barometer setting %	read/write permission
		high pressure type	low pressure type		
0001H	OUT1 Pressure value	-100~1000	-1013~1013	NC	R
		\updownarrow	\updownarrow		
		-0.101~1.000MPa	-101.3kPa~101.3kPa		
0010H	OUT1 target value	-100~1000	-1010~1010	OUT1 in normal mode	R/W
		\updownarrow	\updownarrow		
		-0.100~1.00MPa	-101.0~101.0kPa		
0011H	OUT1 target upper limit value	upper lower value ~1000	upper lower value ~1010	OUT1 lower limit value in operation mode	R/W
		\updownarrow	\updownarrow		
		target upper lower value ~1.000MPa	target upper lower value ~101.0kPa		
0012H	OUT1 target lower limit value	-100 ~ upper limit value	-1010 ~ upper limit value	OUT1 lower limit value in operation mode	R/W
		\updownarrow	\updownarrow		
		-0.100MPa ~ target upper limit value	-101.0kPa ~ target upper limit value		
0013H	output mode	0~2	0~2	OUT1 Output mode Settings	R/W
		\updownarrow	\updownarrow		
		EASY, HYS, WCMP	EASY, HYS, WCMP	Simple mode Lag mode Window mode	
0014H	display color setting value	0~3	0~3	normally displayed in red	R/W
		\updownarrow	\updownarrow		
		R_ON, G_ON, RED, GREEN	R_ON, G_ON, RED, GREEN	normally displayed in green	
0015H	unit setting value	0~4	1~6		R/W
		\updownarrow	\updownarrow		
		MPa, kPa, kgf/cm ² , bar, psi	kPa, kgf/cm ² , bar, psi, mmHg, inHg		
0016H	normally open and normally closed setting value	0~1	0~1	normally open/normally closed mode setting	R/W
		\updownarrow	\updownarrow		
		NO, NC.	NO, NC.		

Function code	realized function	exception code	exception description
03H	Read value of multiple registers	01H %	Function code error, code other than 03,04,06,10 is used
04H	read current air pressure value	02H %	illegal data address, out of address range or read/write permission
06H	write value of single register	03H %	Illegal data, number of data exceeds the limit or error count
10H	write value of multiple registers	04H %	Parameter setting error, parameter setting value is written out of the setting range

Note

- *1 For wiring definition, please refer to "C. Wiring".
- *2 Baud rate can be selected from 9.6kpbs, 19.2kpbs, 38.4kpbs, 115.2kpbs, default is 19.2kpbs.
- *3 Address setting range 1~247, default is 12H; *4.
- *4 When the exception code is 01H, the response function code is 89H; *5.
- *5 When the exception code is 02H/03H/04H, the response function code = request function code + 80H. Example: If the request function code is 03H, the response function code is 83H.
- *6 For setting information, refer to "G. Basic Operation in $\lt; \text{Operation Mode}$" and "1 Normal Setup Mode"

Zero calibration



Press the **S** and **V** keys simultaneously in Run Mode until the display reads



Release the keys at this time to complete the zero calibration operation.

Key lock



Press the **S** and **V** keys simultaneously in Run Mode until the display reads



key lock


Release the key at this time to complete the key lock/unlock operation

Display value fine-tuning function

Expert setting mode



Setting ratio by **S** **V**



1. This function is designed to eliminate the very slight pressure error, do not change the default value when it is not necessary to avoid misunderstanding.
2. If there is analog output after the adjustment takes effect, it will be changed accordingly.

Error messages

realized function	error description
ERR 1	Abnormal current consumption of switching output port
ERR 2	zeroing call added air pressure on time
### #	pressure value out of range
ERR 3	internal error
ERR 4	internal error

for more information, please contact us, we will be happy to serve you!

Precautions for use

1. This product is suitable for non-corrosive gas, do not use in corrosive, flammable gas and any liquid.
2. Do not use this product on any testing device used for human protection.
3. Please use the product within the limited air pressure range, otherwise it will cause abnormal function or damage.
4. Please use this product within the rated voltage range and ensure that the voltage fluctuation does not exceed the rated range.
5. Please refer to the wiring method in the specification. Incorrect wiring may cause failure or damage to the product.
6. Connect and assemble with the power off.
7. Do not use this product in an environment with a lot of water vapor or dust.
8. Do not put this product in direct contact with water, grease, organic solvents, etc.
9. Do not tie the cable of this product with the power cord with high voltage to avoid interfering with the use of this product.